

NOTES:

- 1. LAYOUT AND TAP LOCATION SHALL BE APPROVED BY THE CPU INSPECTOR PRIOR TO EXCAVATING. THE TAPPING COMPANY SHALL CONTACT THE CPU INSPECTOR TWO(2) WORKING DAYS IN ADVANCE PRIOR TO SCHEDULING THE HOT TAP.
- 2. HOT TAPS MAY ONLY BE DONE BY A CPU APPROVED TAPPING CONTRACTOR
- 3. THE CPU INSPECTOR SHALL BE AT THE WORKSITE DURING TAPPING OPERATIONS.
- 4. THRUST BLOCK SHALL BE POURED AGAINST FIRM UNDISTURBED SOIL. USE PLASTIC OR OTHER PROTECTIVE MATERIAL BETWEEN PIPE FITTINGS AND THRUST BLOCK.
- 5. TRENCH EXCAVATIONS OVER 4' WILL REQUIRE SHORING OR OTHER MEASURES CONSISTENT WITH APPLICABLE LOCAL, STATE OR FEDERAL SAFETY CODES.
- 6. ALLOW MINIMUM 24 HOURS FOR CONCRETE THRUST BLOCK TO CURE PRIOR TO CONNECTING TO PIPING.

REVISED JANUARY 2025

