

## **NOTES:**

- 1. APPROVED REDUCED PRESSURE BACKFLOW ASSEMBLY TO BE INSTALLED ABOVE GROUND ONLY WITH MINIMUM CLEARANCES.
- 2. DESIGNED FOR BACK SIPHONAGE AND BACK PRESSURE.
- 3. TEST COCKS TO EITHER FACE OUTWARDS OR UPWARDS FROM ASSEMBLY.
- 4. DISINFECT, PRESSURE TEST AND THOROUGHLY FLUSH LINES PRIOR TO INSTALLATION OF BACKFLOW PREVENTER.
- 5. DO NOT INSTALL IN AN AREA SUBJECT TO FLOODING.
- 6. MUST BE PROTECTED FROM FREEZING CONDITIONS INSIDE AN INSULATED BOX COMMONLY REFERRED TO AS A HOT BOX.
- 7. THE BACKFLOW ASSEMBLY SHALL BE A STATE APPROVED MODEL.
- 8. A PLUMBING PERMIT IS REQUIRED. PLEASE CONTACT YOUR LOCAL PLUMBING PERMIT CENTER.
- 9. MUST BE TESTED AFTER INSTALLATION AND YEARLY THEREAFTER BY A WASHINGTON STATE CERTIFIED BACKFLOW ASSEMBLY TESTER. TEST RESULTS SHALL BE SENT TO CLARK PUBLIC UTILITIES WATER SERVICES.

**REVISED JANUARY 2025** 

FILE NAME		STANDARD RPBA
21W		(REDUCED PRESSURE BACKFLOW ASSEMBLY) 2" & SMALLER
SHEET	1 OF 1	STANDARD DETAILS

